



Interfit Quick Start Guide

A Power Indicator	E Modeling Lamp Button	I Beep Button
B Power Button	F Test Button	J Battery Compartment
C LCD Screen	G Power Adjust Buttons	K Micro USB Port
D Channel Button	H Group Button	L Hot Shoe Interface



Turning the Unit On and Off	Modeling Lamp	Beep
<ol style="list-style-type: none"> 1. Install AAA batteries. 2. Press and hold the power button B for 2 seconds to turn the unit on and off. 	<p>Press E once to set modeling lamp to proportional brightness, once again to set modeling lamp to 100% brightness, and a third time to turn the modeling lamp off.</p>	<p>Press I to toggle audible remote adjustment and recycle tone on and off.</p>
Setting Groups and Channels	Tech Specs	Compatibility
<p>Press D to toggle through channels 1-15.</p> <ul style="list-style-type: none"> • Both the flash head and the remote must be on the same channel <p>Press H to toggle through groups A-H.</p> <ul style="list-style-type: none"> • Assigning groups allows you to individually control the lights via the remote • Setting the group to “.” by pressing and holding H will disable all radio communication 	<ol style="list-style-type: none"> 1. frequency: 2.4GHz 2. voltage: 2.0-3.4Vt 3. sync speed: 1/250s 4. wireless range: 100 meters 	<p>This remote is compatible with the Interfit S1, Interfit S1a and the Honey Badger.</p> <ul style="list-style-type: none"> • When setting groups, the S1 and S1a can only be used on groups A-C and channels 1-8 • This remote cannot be used in TTL or HSS mode.
	Micro USB	
	<p>The micro USB port can be used to supply constant power to your remote while in use.</p>	